KITCHEN SINK ACCESSORY

Stainless Steel Soap Dispenser for Kitchen Sink 300ml Silver

Silver

Model **SD-785**



Scan for the product page, videos and spare parts

Please read this manual before installing and keep it for future reference.

Edition 1 · November 2026

Contents

1. Safety first
2. Know your product
3. What is in the box
4. Specifications
5. Installation
6. How to use
7. Care and cleaning
8. Troubleshooting
9. Warranty and support

1 Safety first

> **Important** Read these points before you start. Ignoring them can cause injury, leaks or damage that the warranty does not cover.

- ✓ Turn off the water supply before you start, and keep it off until all joints are tight.
- ✓ We recommend installation by a qualified plumber.
- ✓ Wear gloves. Cut steel edges and stone edges can be sharp.
- ✓ Lift heavy items with two people.
- ✓ Before drilling or cutting, check for hidden pipes and electric wires.
- ✓ Do not stand or sit on sinks or basins, and do not let children hang on faucets or accessories.

2 Know your product

This manual explains how to install, use and look after your Fossa kitchen sink accessory. Keep it with your invoice.

- ✓ Built with premium stainless steel and a sleek silver finish, offering exceptional durability, rust resistance, and long-lasting performance for everyday kitchen use.
- ✓ Designed with a smooth, easy-press pump mechanism that ensures effortless and consistent dispensing of handwash, dish soap, or sanitiser.
- ✓ Leak-resistant construction prevents spills and ensures clean, mess-free usage, offering a secure fit on most modern kitchen sink tops.
- ✓ Stainless steel body with protective coating resists stains, odours, and bacterial buildup, keeping your sink area fresh and hygienic.
- ✓ Strong, sturdy construction ensures smooth pump action and consistent dispensing even with long-term daily use.
- ✓ Smooth stainless steel finish cleans effortlessly and retains its shine with minimal care—ideal for busy kitchens.
- ✓ Perfect for modern kitchens, restaurants, cafés, offices, and commercial spaces—an essential accessory for organised and efficient kitchen sink setups.

3 What is in the box

1. 1 × Stainless Steel Soap Dispenser with 300ml Refillable Bottle (Silver)

4 Specifications

Model / SKU	SD-785
Product type	Kitchen sink accessory
Material	Stainless steel
Colour / finish	Silver
Shipping weight	0.19 kg

5 Installation

> Deck-mounted items (glass rinser, soap dispenser) need a free hole in the sink or counter. Loose items need no installation.

Tools you will need

- Adjustable spanner (deck-mounted items only)

1. **Unpack and check** Check every part against "What is in the box".
2. **Deck-mounted items** Pass the body through the free hole, fit the washer and nut from below, and tighten by hand. Connect the water hose if the item has one.
3. **Loose items** Baskets, boards and trays simply rest on the sink. Adjust the length (if adjustable) to fit across the bowl.
4. **Test** For items with water, open the supply and check for drips.

6 How to use

Using the accessory

1. Soap dispenser: fill the bottle from above or below, then press the pump.
2. Glass rinser: place a glass upside down and press down to rinse.
3. Basket or board: set it across the bowl to rinse, drain or chop.

7 Care and cleaning

- ✓ Clean periodically with mild soap and water to maintain hygiene and shine.
- ✓ Avoid harsh chemicals or abrasive scrubbers to protect the stainless steel finish and pump mechanism.
- ✓ Refill the bottle as needed and ensure the pump remains unclogged for smooth performance.
- ✓ Wipe dry after washing to prevent water spots and maintain a polished appearance.
- ✓ Keep the nozzle clean for consistent and efficient soap flow.

8 Troubleshooting

Problem	Likely cause	What to do
Dispenser pump stiff	Soap too thick.	Mix a little water into the soap.
Rinser keeps spraying	Debris under the plate.	Close the supply, lift and clean the plate.
Wobbles on the deck	Nut loose.	Tighten the nut from below.

9 Warranty and support

Product	1 year against manufacturing defects
Return or replacement	Within 10 days of delivery for damage, defect or wrong product

How to make a claim

1. Keep your invoice or order number. It is your proof of purchase.
2. Take clear photos or a short video of the problem, and a photo of the product label or SKU.
3. Contact us by WhatsApp, phone or email with your order number and the photos.
4. Our team checks the claim and arranges a repair, part or replacement.

The warranty does not cover

- Damage from wrong installation, misuse, accidents, or dropping the product.
- Damage from harsh chemicals, abrasive cleaners or very hard water left on the surface.
- Normal wear, such as worn washers, and scratches from daily use.
- Products changed or repaired by someone other than Fossa.

Chat on WhatsApp

Fossa customer support

WhatsApp / phone +91 98113 21235
Landline 011-6926 8726
Email support@fossahome.com
Hours Monday to Saturday, 10 AM to 7 PM
Web www.fossahome.com

© 2026 Fossa Home. Product photos are for illustration. Diagrams are not to scale. Fossa may improve products without notice.