WASTE COUPLING / TRAP / PIPE

Flexible Wash basin Pipe with Cup Trap (White)

White

Model **WP-003White**



Scan for the product page, videos and spare parts

Please read this manual before installing and keep it for future reference.

Edition 1 · November 2026

Contents

1. Safety first
2. Know your product
3. What is in the box
4. Specifications
5. Installation
6. How to use
7. Care and cleaning
8. Troubleshooting
9. Warranty and support

1 Safety first

> **Important** Read these points before you start. Ignoring them can cause injury, leaks or damage that the warranty does not cover.

- ✓ Turn off the water supply before you start, and keep it off until all joints are tight.
- ✓ We recommend installation by a qualified plumber.
- ✓ Wear gloves. Cut steel edges and stone edges can be sharp.
- ✓ Lift heavy items with two people.
- ✓ Before drilling or cutting, check for hidden pipes and electric wires.
- ✓ Do not stand or sit on sinks or basins, and do not let children hang on faucets or accessories.

2 Know your product

This manual explains how to install, use and look after your Fossa waste coupling / trap / pipe. Keep it with your invoice.

- ✓ Made from high-quality PP (Polypropylene) material, delivering excellent flexibility, crack resistance, and long-lasting performance for everyday Wash basin drainage.
- ✓ Flexible pipe design ensures smooth, uninterrupted water flow, while the cup trap effectively collects debris to help prevent blockages and foul odours.
- ✓ Precision-engineered, leak-resistant joints provide a tight and secure connection, preventing water seepage during regular use.
- ✓ Smooth, non-porous PP surface resists stains, odours, and bacterial buildup, keeping the sink area clean, fresh, and hygienic.
- ✓ Reinforced construction ensures stable water flow and dependable performance, even under continuous kitchen usage.
- ✓ Cup trap allows easy opening and cleaning, while the flexible pipe requires minimal maintenance—ideal for busy households.
- ✓ Suitable for modern homes, restaurants, cafés, offices, and commercial kitchens—a practical solution for efficient and reliable sink drainage.

3 What is in the box

1. 1 × Flexible Wash basin Pipe with Cup Trap (White)

4 Specifications

Model / SKU	WP-003White
Product type	Waste coupling / trap / pipe
Colour / finish	White

5 Installation

> Measure the drain hole of your sink or basin first and check it matches this fitting.

Tools you will need

- Adjustable spanner
- Silicone (if needed)
- Bucket and cloth



Not to scale

1. **Check the size** Check the fitting matches your sink or basin drain hole and your waste pipe.
2. **Fit the top part** Put the rubber washer under the flange and set it in the drain hole from above.
3. **Tighten from below** Fit the lower washer and lock nut from below. Tighten by hand, then a little more with a spanner.
4. **Connect the pipe** Connect the waste pipe or trap and run it to the drain.
5. **Test** Fill the sink or basin, then let it drain and check every joint for drips.

6 How to use

Everyday use

1. Keep the strainer or basket in place to catch food and hair.
2. Pop-up wastes: press the top to close and press again to open.

7 Care and cleaning

- ✓ Clean periodically with mild soap and water to maintain hygiene and drainage efficiency.
- ✓ Avoid harsh chemicals or abrasive tools to protect flexibility and surface finish.
- ✓ Open and clean the cup trap occasionally to remove collected debris and prevent blockages.
- ✓ Ensure all connections remain securely tightened.
- ✓ Wipe dry after cleaning to prevent residue buildup.

8 Troubleshooting

Problem	Likely cause	What to do
Leak at the drain hole	Washer not seated.	Re-seat the washer and tighten the lock nut.
Slow drain	Basket or trap blocked.	Empty the basket or open and clean the trap.
Bad smell	Trap dry or dirty.	Clean the trap and run water to refill it.

9 Warranty and support

Product	1 year against manufacturing defects
Return or replacement	Within 10 days of delivery for damage, defect or wrong product

How to make a claim

1. Keep your invoice or order number. It is your proof of purchase.
2. Take clear photos or a short video of the problem, and a photo of the product label or SKU.
3. Contact us by WhatsApp, phone or email with your order number and the photos.
4. Our team checks the claim and arranges a repair, part or replacement.

The warranty does not cover

- Damage from wrong installation, misuse, accidents, or dropping the product.
- Damage from harsh chemicals, abrasive cleaners or very hard water left on the surface.
- Normal wear, such as worn washers, and scratches from daily use.
- Products changed or repaired by someone other than Fossa.

Chat on WhatsApp

Fossa customer support

WhatsApp / phone +91 98113 21235
Landline 011-6926 8726
Email support@fossahome.com
Hours Monday to Saturday, 10 AM to 7 PM
Web www.fossahome.com

© 2026 Fossa Home. Product photos are for illustration. Diagrams are not to scale. Fossa may improve products without notice.