WASTE COUPLING / TRAP / PIPE

Waste pipe with Coupling Double bowl kitchen sink silver

Silver

Model **CPH-2**



Scan for the product page, videos and spare parts

Please read this manual before installing and keep it for future reference.

Edition 1 · November 2026

Contents

1. Safety first
2. Know your product
3. What is in the box
4. Specifications
5. Installation
6. How to use
7. Care and cleaning
8. Troubleshooting
9. Warranty and support

1 Safety first

> **Important** Read these points before you start. Ignoring them can cause injury, leaks or damage that the warranty does not cover.

- ✓ Turn off the water supply before you start, and keep it off until all joints are tight.
- ✓ We recommend installation by a qualified plumber.
- ✓ Wear gloves. Cut steel edges and stone edges can be sharp.
- ✓ Lift heavy items with two people.
- ✓ Before drilling or cutting, check for hidden pipes and electric wires.
- ✓ Do not stand or sit on sinks or basins, and do not let children hang on faucets or accessories.

2 Know your product

This manual explains how to install, use and look after your Fossa waste coupling / trap / pipe. Keep it with your invoice.

- ✓ Built with high-quality, corrosion-resistant materials, offering exceptional durability, long-lasting performance, and reliable drainage for double bowl kitchen sinks.
- ✓ Engineered to ensure smooth, fast, and uninterrupted water flow from both sink bowls, preventing clogs and maintaining optimal drainage efficiency.
- ✓ Leak-proof sealing and precision-fit connectors prevent water seepage, offering a stable and dependable drainage setup for everyday kitchen use.
- ✓ Odour-resistant and easy-to-clean construction helps prevent bacterial buildup and unpleasant smells, keeping your under-sink area fresh and hygienic.
- ✓ Strong structure provides excellent stability under continuous water flow, delivering dependable performance for busy kitchens.
- ✓ Smooth surfaces and accessible joints make cleaning simple, ensuring minimal maintenance and long-term functionality.
- ✓ A perfect fit for modular kitchens, double bowl sinks, restaurants, cafés, and commercial setups—an essential component for efficient drainage management.

3 What is in the box

1. 1 × Silver Coupling Set for Double Bowl Kitchen Sink

4 Specifications


Model / SKU	CPH-2
Product type	Waste coupling / trap / pipe
Colour / finish	Silver
Shipping weight	0.32 kg

5 Installation

> Measure the drain hole of your sink or basin first and check it matches this fitting.

Tools you will need

- Adjustable spanner
- Silicone (if needed)
- Bucket and cloth



1. **Check the size** Check the fitting matches your sink or basin drain hole and your waste pipe.
2. **Fit the top part** Put the rubber washer under the flange and set it in the drain hole from above.
3. **Tighten from below** Fit the lower washer and lock nut from below. Tighten by hand, then a little more with a spanner.
4. **Connect the pipe** Connect the waste pipe or trap and run it to the drain.
5. **Test** Fill the sink or basin, then let it drain and check every joint for drips.

6 How to use

Everyday use

1. Keep the strainer or basket in place to catch food and hair.
2. Pop-up wastes: press the top to close and press again to open.

7 Care and cleaning

- ✓ Clean periodically with mild soap and water to remove debris and maintain smooth drainage.
- ✓ Avoid harsh chemicals that may damage the material over time.
- ✓ Check the connections periodically to ensure a tight, leak-free fit.
- ✓ Keep the drain area clear of food waste to prevent blockages.
- ✓ Inspect seals regularly to maintain optimal drainage performance.

8 Troubleshooting

Problem	Likely cause	What to do
Leak at the drain hole	Washer not seated.	Re-seat the washer and tighten the lock nut.
Slow drain	Basket or trap blocked.	Empty the basket or open and clean the trap.
Bad smell	Trap dry or dirty.	Clean the trap and run water to refill it.

9 Warranty and support

Product	1 year against manufacturing defects
Return or replacement	Within 10 days of delivery for damage, defect or wrong product

How to make a claim

1. Keep your invoice or order number. It is your proof of purchase.
2. Take clear photos or a short video of the problem, and a photo of the product label or SKU.
3. Contact us by WhatsApp, phone or email with your order number and the photos.
4. Our team checks the claim and arranges a repair, part or replacement.

The warranty does not cover

- Damage from wrong installation, misuse, accidents, or dropping the product.
- Damage from harsh chemicals, abrasive cleaners or very hard water left on the surface.
- Normal wear, such as worn washers, and scratches from daily use.
- Products changed or repaired by someone other than Fossa.

Chat on WhatsApp

Fossa customer support

WhatsApp / phone +91 98113 21235
Landline 011-6926 8726
Email support@fossahome.com
Hours Monday to Saturday, 10 AM to 7 PM
Web www.fossahome.com

© 2026 Fossa Home. Product photos are for illustration. Diagrams are not to scale. Fossa may improve products without notice.